



Date : 2020-4-7

TEL:

Version: V3.0 ATCCA01

FAX:

Q1-Series PACs Debugging Tutorial V3.0

Overview

This manual is just for the simple debugging of Q1 controller of V3.0 on the CODESYSV3.5 SP13/14 platform, as the software and hardware of Q1 controllers will update anytime, the manual will also be updated from time to time.

Files contained in the document

File name	File description
Q1-series PACs Debugging Tutorial.pdf	Operation procedures
Q1test.pro	Test program
HCQ1-1300-D-V301.package	Device description file required by Q1 controller
HCFA_X3E_ESI.xml	Description file for X3E Series

Version Updates

V1.0 Nov. 19th, 2018

V1.01 Dec. 11th, 2018 Update the description file installation in Appendix A

V1.1 Dec. 18th, 2018 Update Wiring diagram; Add Trace

V2.0 Jul. 1st, 2019 Update the Linux platform of Q1 controller, high-speed IO and remote extension modules

V3.0 Apr.7th, 2020 Update local extension, high-speed input/output, communication library.etc

Disclaimer

We have tested the content described in this manual. However, mistakes are inevitable, and there is no guarantee that it is absolutely correct and fully meets your needs. And the manual may change without notice, and your improvement suggestions are also welcome.


For any questions, feel free to email: wujingwen@hcfa.cn




Q1-Series PACs Debugging Tutorial V3.0-----	1
Overview-----	1
Files contained in the document-----	1
Version Updates-----	1
Disclaimer-----	1
Q1-Series PACs Debugging Tutorial-----	3
1 Create CODESYS project-----	7
2 Select target device and programming language-----	7
3 Establish communication with Q1 controller-----	8
4 Create PLC Project-----	9
4.1 Add Library-----	9
4.2 Task setting-----	10
4.3 PLC programming-----	11
4.4 Add Trace to monitor Program Variables-----	14
5 Program download and online monitoring-----	16
5.1 PLC program compiling and download-----	16
5.2 Log in and running-----	16
5.3 Online monitoring-----	18
5.4 Reset function-----	19
6 Built-in high-speed IO debugging description-----	20
6.1 As the general input/output-----	20
6.2 As the high-speed input/output-----	21
7 Add extension modules (including local extension)-----	26
8 Creat Motion project-----	27
8.1 Add SoftMotion project (without adding remote extension modules)-----	27
8.2 Modify EtherCAT master station information and communication parameters-----	29
8.3 Single-axis motion control instructions-----	30

Q1-Series PACs Debugging Tutorial


The Q1-series PACs are the multifunctional standard controller based on CODESYS programming and debugging platform. This manual will introduce how to test Q1-series PACs on the CODESYS platform, including how to use the local high-speed input and output, Q series couplers and remote extension I/O (currently introduce digital And analog input and output), single-axis and two-axis motion control. Compared with the V2.0, the main changes are as follows. Refer to [Appendix D](#) for the version view method.

Items	V205 (Hardware 2.0)	V301 (Hardware 3.0)
Power supply terminal	No mounting hook	With mounting hook, firmly stuck
	GND: Close to DIN rail , 24V: Close to indicators	
Local extension	Not supported	Local extension power: Max. 16W
Terminal block	Only parallel crimping pliers	Not defined, meet the requirement of wire diameter
COM. port	N/A	Add the guide plastic sheet
High-speed I/o	8-ch high-speed inputs, no high-speed output	8-ch high-speed input, added 8-ch high-speed outputs
Serial communication	2-ch RS485	2-ch RS485 , added 1-ch RS232
Modbus	Support ModbusTCP Support Modbus RTU	Tree-type for communication function, as shown below 

The test platform consists of Q1 controller, EC coupler (HCQX-EC), digital I/O (HCQX-ID/OD16-D), Analog I/O (HCQX-AD/DA04-D), X3E series servo drive (SV-X3EA010A-A2-EC) and X3 series servo motor (SV-X3MM010A-N2LA), the wiring diagram is shown below :




- ① RJ45 interface , programming interface, connected to the host PC and supports the Ethernet protocol
- ② RJ45 interface , programming interface, connected to the host PC and supports the Ethernet protocol
- ③ EtherCAT master interface , support EtherCAT protocol
- ④ Run-Stop dial switch , Run on the right
- ⑤ EC coupler module establish the communication with host CPU unit via network cable through the bottom network port (EtherCAT protocol)




Note EC coupler module needs the customized network cable, and the customized network cable and adapter are provided with the EC coupler.

- ⑥ Digital I/O module , For channel definition and wiring, please refer to the digital input module channel and wiring




Wiring diagram




*SS internal short-circuit, Not connected in other channels, take I8~I15 as example.

Digital output module channel and wiring



Wiring diagram




*COM internal short-circuit, not connected in other channels, take channel 8-15 as example


⑦ Analog I/O module

Analog input module channel and wiring (24VDC needs to be connected at the top of analog module as the load power supply)

Voltage differential and single-end input internal circuit diagram



Current input internal circuit diagram




*1 Equipotential connection

名称	端子		名称
V1-	0	9	V1+
G	1	10	I1
V2-	2	11	V2+
G	3	12	I2
V3-	4	13	V3+
G	5	14	I3
V4-	6	15	V4+
G	7	16	I4
G	8	17	G

Analog output module channel and wiring (24VDC needs to be connected at the top of analog module as the load power supply)

Voltage output internal circuit diagram





名称	端子		名称
V1	0	9	G
I1	1	10	G
V2	2	11	G
I2	3	12	G
V3	4	13	G
I3	5	14	G
V4	6	15	G
I4	7	16	G
G	8	17	G

⑧ EC module network cable

After completing the wiring and power supply, add the PLC program in CODESYS to debug the module and servo drive.

1 Create CODESYS project


After installing the CODESYS software, find  on the desktop. Double-click the software to find the New Project in the startpage or find File – New Project in the menu.



The user can select the desired project type, enter the project name and path, and then click "OK"


2 Select target device and programming language

According to the default guidance of CODESYS, select the target device and the programming language of the main program PLC_PRG. Then install the Q1 main unit or you cannot select the correct target device. Refer to [Appendix A](#) for the installation steps of the new device description file.




3 Establish communication with Q1 controller


The default IP address of Q1 controller Port1 is: 192.168.188.100 Subnet mask: 255.255.255.0. Modify the IP to the same network segment in the PC network adapter (Default IP address of Port2: 192.168.88.xxx Subnet mask : 255.255.255.0)



Double-click Device→Scan network. After scanning to Q1, select the device and click OK.



The correctly added device is shown as follows.




4 Create PLC Project

A standard PLC project, including libraries, tasks and programs, and you can also add tracking to real-time monitor the variables in the program.


4.1 Add Library

If a project needs to use an external library, users are required to install the library files. Double-click Library Manager on the left, enter the library file manager, find the Library repository → install → the library file to be installed → OK, to install the library file.




CODESYS can identify the library version automatically and support switching between multiple versions of library files. If you need to uninstall, just select the library file that needs to be uninstalled → click the uninstall button.

The installed library can be found in the Add library.




4.2 Task setting

Tasks can be managed in the task configuration. A new standard PLC project will automatically generate a cyclically executed task. The task is automatically associated with PLC_PRG. The default Interval is 4ms, and the Priority is 1 and the PLC program can compile and execute only when called by the task. Right-click the Task Configuration → Add Object → Task, define the task name to complete the creation of a new task. The different types of tasks can be created up to 100, according to the priority order set by the user, the smaller the number, the higher the priority. In the case of the same priority, they are executed according to the order in the task configuration.




For the new PLC program created by the user, you need to manually configure and call the task, otherwise the program will not be executed. Double-click Main Task → Add Call → Select the PLC program to be called and click OK.




4.3 PLC programming

To add a new POU (Program Organization Unit). Right-click Application → Add Object → POU, Enter the name, select the block type, support six programming languages, select Structured Text (ST) to write example programs.



Double-click PLC_PRG to enter the programming interface. From top to bottom, there are Variable declaration window, Main program window and Message window. The errors, warnings in compilation and compilation information will shown in the Message window.



The example program writing is shown as below:

First, declare the variables that need to be used in the program in accordance with the IEC61131-3 programming standard,

The variable declaration: Variable name: Variable data type: = Initial value; The initial value may not be given, the variable has a default initial value, single-line comments are made through "//", and Chinese comments are supported, but the cursor position may display incorrectly, so English comments are recommended to use for the time being.

In the variable declaration window, press Shift+F2 to show the dialog box of Automatic Declaration, where the name and type must be entered.

Scope : Variable scope

Name : Variable name

Type : Variable data type



Object : Variable application

Initialization : Variable initial value

Address : Mapping between variables and external ha


Flags: Variable type can be set to Constant, Retain and Persistent

Comment : Comment, format (*contents*)





Write the example program in the main program window. The correctly declared variables can be called by F2 in the main program window. Pay attention to the calling type.

Variable: Single variable, need to be declared




Module call: function call, no need to declare






Example call: Function block statement, need to be declared




Write the example program according to the above rules :




4.4 Add Trace to monitor Program Variables


Right-click Application→Add Object→Trace. Trace will appear in the tree menu on the left after successful adding.




Double-click to enter the Trace page for configuration




Click the configuration button in the upper right corner of the Trace interface to add and delete monitoring variables and set the sampling period. After opening the Trace page, add and delete variables through the add/delete variable buttons in the lower left corner.



Click the Task followed by the sampling cycle on the left menu, drop down to select the Main Task for example.




After completing the basic configuration of Trace, you need to log in the program and run it normally before you can download and start the trace (Start Trace) anywhere on the Trace interface and observe the variable running trace. Otherwise, the item is grey by default and cannot be selected




5 Program download and online monitoring


5.1 PLC program compiling and download

After the PLC program writing is done, the program needs to be compiled before downloading. The building command will check the grammar and the POU must be added to the Task, or not compiling. Select the Build → Build, the compiling result will show in the message window after executing the compile command, and the information that needs to be viewed can be displayed separately by selecting errors, warnings and messages.





5.2 Log in and running


When no errors in compiling the program, we can log in. Find the login-in icon  in the toolbar and enter into the program online monitoring.




A dialog box pop-up: The downloaded application will replace the existing application in the PLC. To continue to download? Then click "Yes".




After logging in successfully, click  to run the program.




The operation interface of the program is as follows.



Start Trace to collect the running Trace of the variable.




Right-click anywhere on the Trace page to pause or start the trace. Move the mouse to observe the History trace and the scroll wheel can zoom in and out of the trace waveform.




5.3 Online monitoring


After the program logged in and run successfully, the actual value of the variable will display on both the main program window and the declaration window. If the user wants to monitor multiple POU's at the same time, gather the variables that need to be observed and find View→Watch→Watch 1 in the menu bar, and the program will automatically create Monitoring List 1. And 4 monitoring lists can be created.




Choose Monitor 1, click the empty column, you can directly call the variables or global variables in different POU by clicking the index, or you can click [...] on the right to expand to add the variables that need to be monitored online.



After the configuration completed, you can view the real-time value of the variable through the "Monitor 1" under the message window during the normal operation of the program, and assign values to the current variable. You can manually add or delete the monitoring variable even during the normal operation.





After logging in, you can enter the value you want to write in the next cycle in the preparation value. This operation can be completed in the Variable declaration window, Main program window and Monitoring window. After inputting values, choose Debug → Write values to write the correct value. In CODESYS, users can assign values to variables in two ways: Write value (Ctrl+F7) and Forced value (F7). The value written by forced value will be identified **F** on the left, which can be restored by releasing the value.



5.4 Reset function

In debugging, if the user wants to reset the program, there are three reset methods: Reset warm, reset cold and reset origin. Three methods can be selected in the "Online". After clicking execute, a dialog box will pop up for confirmation. The effect of different instructions on different types of variables defined in the program after execution is shown in the following table.



Note : X : Retention value O : Initial value


Online instruction	VAR	VAR RETAIN	VAR RETAIN PERSISTENT
Warm reset	O	X	X
Cold reset	O	O	X
Initial value reset	O	O	O
Download	O	O	X
Online change	X	X	X


6 Built-in high-speed IO debugging description

Q1 controllers are built-in high-speed input and output, and the high-speed input and output ports can also be used as general input and output.

6.1 As the general input/output


The wiring for general input/output can refer to digital input/output module, supporting PNP/NPN. First, you need to install the corresponding description file in the device manager. For the detailed process, please refer to [Appendix A](#). After the installation completed, make sure that Q1 controller can communicate with CODESYS normally, and click LocalDevice→Add Device.





The wiring method of the local IO in this mode can directly refer to the wiring method of the digital input module. After adding finished, you can monitor the current local IO status or perform test output under the General I/O mapping on the right.


Please note that when there is no program test, the IO refresh cycle needs to be selected as: Always in the bus cycle task, otherwise the IO with unmapped variables will not be refreshed, and the current IO will be refreshed with the program variables if the program variables are mapped.



6.2 As the high-speed input/output

When the local IO is used as a high-speed input port, the wiring method is as follows :


- 1) Wiring for high-speed input (take channel 1 as the example)




Channel	Port	Port	Channel
hsi_cnt	X0	X8	hsi_cnt4
	X1	X9	
hsi_cnt1	X2	X10	hsi_cnt5
	X3	X11	
hsi_cnt2	X4	X12	hsi_cnt6
	X5	X13	
hsi_cnt3	X6	X14	hsi_cnt7
	X7	X15	

High-speed input supports PNP and NPN, wiring method depends on the input type of the encoder. For the input signal of PNP type, connect 0V to the common terminal; If NPN type, connect 24V. And the common terminal is internally connected.

2) Wiring for high-speed output (No high-speed output function temporarily, will be improved)
 At the same time, you can add General IO, but for input (output), only one input (output) method can be selected. When using the high-speed input, you need to install the device description file contained in the folder: The file in HIS_Counter_Drv and LocalHSInput.xml. Refer to [Appendix A](#) for the installation steps. After the installation completed, LocalDevice→Add Device→to add high-speed IO in LocalHSInput.





After adding, click LocalHSInput→Add Device to add the high-speed input channel. Max.8 channels can be added. Refer to the following table for corresponding relationships :

Channel	Port	Port	Channel
hsi_cnt	X0	X8	hsi_cnt4
	X1	X9	
hsi_cnt1	X2	X10	hsi_cnt5
	X3	X11	
hsi_cnt2	X4	X12	hsi_cnt6
	X5	X13	
hsi_cnt3	X6	X14	hsi_cnt7
	X7	X15	


HCFA added the corresponding library files for high-speed IO, so you need to install hcfa.lib.compiled-library before use. After the installation completed, find the function block named hsi_ref in the library file. Add this function block to the main program and enter the corresponding port to use high-speed input. A brief description of the function block is as follows:

FUNCTION_BLOCK hsi_ref

InOut:

Scope	Name	Type	Comment
Input	wDriveID	WORD	
	bCounterEnable	BOOL	
	bEventEnable	BOOL	
	bDspdEnable	BOOL	
	bLatchEnable	BOOL	
	wCountMode	WORD	0: 2-phase-x1; 1: 2-phase-x2; 2: 2-phase-x4; 3: 1-phase-2-input; 4: 1-phase-1-input hardware mode; 5: 1-phase-1-input software mode
	bSoftDirection	BOOL	
	bSoftPreTrg	BOOL	Current Count Value update trigger
	diEventCmpValue	DINT	Event Task compare value
	wHardTrgMethod	WORD	port_Z and port Latch EdgeCheck method;
	wCmpoutCtrlword	WORD	enable Compare output
	wMeasureUnitTime	WORD	
	wStatus_clr	WORD	
	diSoftPreValue	DINT	Current Count Value update value
	diCntMinValue	DINT	
	diCntMaxValue	DINT	
	bTabCmpEnable	BOOL	
	wStartNum	WORD	
	wEndNum	WORD	
	BZport_sel	BYTE	
Blatch_sel	BYTE		
Output	dwDspdFreqValue	DWORD	
	diCurCountValue	DINT	
	diLatchData	DINT	
	wCounterStatu	WORD	direction,overflow,underflow and so on


Right-click in the main program and add Action to the Add Object. In the pop-up dialog box, select Function Block Diagram (FBD) as the programming language.



Define the variables that need to be used in the function block in the Variable declaration window of the main program as follows :

```
//高速输入功能块端口定义
wDriveID      :WORD;
bCounterEnable :BOOL;
bEventEnable  :BOOL;
bDspdEnable   :BOOL;
bLatchEnable  :BOOL;
wCountMode    :WORD:=0;
bSoftDirection :BOOL;
bSoftPreTrg   :BOOL;
diEventCmpValue:DINT;
wHardTrgMethod :WORD;
wCmpoutCtrlword:WORD;
wMeasureUintTime:WORD;
wStatus_clr   :WORD;
diSoftPreValue :DINT;
diCntMinValue  :DINT:=0;
diCntMaxValue  :DINT:=10000;
bTabCmpEnable  :BOOL;
wStartNum     :WORD;
wEndNum       :WORD;
BZport_sel    :BYTE;
Blatch_sel    :BYTE;
dwDspdFreqValue :DWORD;
diCurCountValue :DINT;
diLatchData    :DINT;
wCounterStatu :WORD;
```

Find his_cnt in the global variable in the newly-added Action, and configure the channel that to be used.



After the configuration completed, set the corresponding parameters to make the counter work in different modes. For the description of different modes and test results, please refer to the attachment.

HCQ1- Input test.xlsx


The high-speed input is temporarily an internal test function. If the test results are different or there are any problems during the test, you can directly contact the HCFA Technology. Please wait for the subsequent official release of the official version. There are no functional blocks and test reports for the high-speed output.

7 Add extension modules (including local extension)


The Q1 controllers of V301 version support local IO extension on the right side with a maximum power of 16W. The following table shows the power of extension modules supported by Q1 controllers. (Data are calculated as 10% to 15% rise, because the metal sheet transmission bus current signal will produce a certain resistance over time, thus consuming part of the power) :

Item	Model name for modules	Power
1	LocalEtherCATDevice	16W
2	HCQX-EC-D	1.344W
3	HCQX-ID16-D	0.78W
4	HCQX-0D16-D	1.32W
5	HCQX-MD-D	1.032W
6	HCQX-AD04-D	1.044W
7	HCQX-DA04-D	1.056W


Right-click Device→Add Device, select EtherCAT Master SoftMotion in the dialog box to add the device.



After the addition completed, select the correct network card and download it to Q1 controller(login in Q1 controller). It is recommended that the user select the network by name so that the program can be matched on more devices (the Mac address of the network port of different devices is different)



After login, right-click EtherCAT_Master_SoftMotion to scan device. It is recommended to add the device by scanning the device. But you also can choose to Add Device.



If an unknown device appears in the scan device dialog box, the user needs to check whether the description file used matches or not. The correctly scanned module is displayed as follows :

Scan Devices		
Scanned Devices		
Devicename	Devicetype	Alias Address
LocalEtherCATDevice	LocalEtherCATDevice	0
HCQX_DAO4_D	HCQX-DAO4-D	0
HCQX_ADO4_D	HCQX-ADO4-D	0
HCQX_EC_D	HCQX-EC-D	0
HCQX_ID16_D	HCQX-ID16-D	0
HCQX_OD16_D	HCQX-OD16-D	0



Local extension

Copy all the devices to the project to complete the module adding. It is important to note that the Q1 controller of 3.0 version supports local extension. When manually adding, you need to add LocalEtherCATDevice to add other modules.



8 Creat Motion project

8.1 Add SoftMotion project (without adding remote extension modules)


Right-clcik Device→Add Device , select EtherCAT Master SoftMotion to add devices.




Right-click EtherCAT Master SoftMotion to add device, At this time, you need to add the servo drive that needs to test in the slave station, select SV-X3E to add device.




Right-click on the added slave station SV-X3E and select Add SoftMotion CiA402 Axis. Click OK when dialog box pops up.




Right-click SM_Drive_GenericDSP402, select Refactoring→Rename 'SM_Drive_GenericDSP402' , and modify it to Axis1 so that the relevant axis variables can be called in the PLC program later.



After renaming, a dialog box pops up, select "OK".




The system will automatically complete the mapping of the axis variable after renaming, click "OK" to complete the axis renaming.




8.2 Modify EtherCAT master station information and communication parameters

Double-click the added EtherCAT master station. First, you need to select the network adapter for communication. Select “Browse” on the right of source address, select the network card ECAT1, and click OK.



Modify the encoder parameter settings in Axis1. For X3E series servo drive, 17-bit encoder, and the increment is 16#20000.



8.3 Single-axis motion control instructions

Create a new POU and name it PLC_Motion to write single-axis motion control instructions. For specific steps, refer to section 4.3 and the motion control instructions are shown as follows :

```


1  PROGRAM POU_Motion
2  VAR
3      fbPower1      :MC_Power;
4      fbJog1       :MC_Jog;
5      bpoweron     :BOOL;
6      bJogfw       :BOOL;
7      bJogbw       :BOOL;
8      Velocity     :LREAL:=20;
9      Acceleration :LREAL:=50;
10     Deceleration :LREAL:=50;
11 END_VAR
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000

```

Add Motion project in CODESYS, EtherCAT_Task will automatically generate in task configuration.

The user needs to manually set the EtherCAT_Task parameters, otherwise the synchronization cycle will be lost during the subsequent axis operation. Double-click Application→Task Configuration→EtherCAT_Task , Call PLC_Motion here. For specific steps, refer to section 4.2 and set the priority to "0".

After modifying the hardware setting, log in and run the program. When the servo drive and axis operate normal, double-click PLC_Motion .



First enable the axis, set bPoweron to TRUE.

POU_Motion x

Device.Application.POU_Motion

Expression	Type	Value	Prepared value	Address	Comm
fbPower1	MC_Power				
fbJog1	MC_Jog				
bpoweron	BOOL	TRUE			
bJogfw	BOOL	FALSE			
bJogbw	BOOL	FALSE			
Velocity	LREAL	20			
Acceleration	LREAL	50			
Deceleration	LREAL	50			

```

1  fbPower1(
2      Axis:= Axis1,
3      Enable TRUE := TRUE,
4      bRegulatorOn TRUE :=bpoweron TRUE ,
5      bDriveStart TRUE :=TRUE ,
6  );
7  fbJog1(
8      Axis:=Axis1 ,
9      JogForward FALSE :=bJogfw FALSE ,
10     JogBackward FALSE :=bJogbw FALSE ,
11     Velocity 20 :=Velocity 20 ,
12     Acceleration 50 :=Acceleration 50 ,
13     Deceleration 50 :=Deceleration 50 ,
14     Jerk:= ,
15

```

After enabling Axis1, set bJogfw to TRUE to positive jogging, and set bJogbw to TRUE to reverse jogging. For editing and using other axis function blocks, refer to CODESYS Online Help:


<https://help.CODESYS.com/>

Appendix A Installation of Device Description File


The library files required by Q1 controller and its extension modules are currently packaged into a package. Users only need to double-click the Package Manager and follow the instructions to install the files, as Method 1. If the user wants to install the XML file separately, please refer to Method 2.

Method 1 :


1. Find Tools → Package Manager → Install, to select the corresponding package manager.




Select Customized installation to make it easier to view the files in the installation package, then select Next.



2. View the files contained in this package in Select Components, and tick the files that need to be installed, and click Next to install.




3. Click Finish to complete the installation.




Method 2 : Take Q1 controller as an example for device description file installation, the rest of the description files are provided in the folder (Including general I/O, X3T servo drive, high-speed counting)


1. Find Tools→Device Repository in the menu bar




2. Click to enter the Device library, select the correct device description file, and click Install.



3. The other device description files also need to be installed.. After the installation completed, the Q1 controller can be found in the device library, and the installation information will show in the dialog box, as shown below by the arrow. For devices that do not need to be used, right-click the device to uninstall it.




- If the user needs to change the PLC program running platform, and the project has been created at this time, you need to right-click Device→Update Device to switch the PLC program.




Appendix B Modifying IP address

- Connect to the device that needs to change the IP address and log in
- Select LocalDevice , open SysConfig→IPAddr in the right window, enter the IP address that needs to be modified in the prepared value, and click Write Parameter, which will take effect after powered off and restarted.




Appendix C Compiling error for Chinese CODESYS



Solutions :

Click Build → Clear All, and then rebuild the program to eliminate the error. This is a problem with the Chinese version of CODESYS, and can be fixed in the next version.



Appendix D Check software and hardware version

The hardware version for Q1 controller can be viewed in the first four digits of the P/N on the label, as shown in the figure: V3.01.



The software version for Q1 controller can be found when scanning to add Q1 controller, as shown in the figure: V322 .

